



Quattrocanali, Duecanali Dante™ FW Update



Tech Note

All copyright and industrial rights in this document and in the technical knowledge it contains are owned by Powersoft and/or the third parties rightfully concerned.
No part of this document nor any data herein shall be disclosed, reproduced or used for any purpose whatsoever without the prior written consent of POWERSOFT as foreseen by the law.
Drawings and specifications are subject to change.
All trademarks and registered trademarks are the property of their respective holders.

1. Introduction

Hardware

To update the Dante firmware version you need first to select the correct firmware file depending on your hardware.


At the time of writing there are two different Dante board for Quattrocanali\Duecanali models:

- Uxt
- Ult


2. Checking your Dante Board Version

To check your Dante board version:


1. Open Dante Controller and double click on the device you want to check. A device detail window will pop up.



2. Click on the “Status” tab on the device detail window.



3. From the status check the “Model” field in the “Dante Information” box:
- if it is reported to be Ultimo4 then you are using a ULT Dante board
 - if it is reported to be UltimoX4 then you are using a UXT Dante board



Now you can proceed to the firmware update by using the Dante Firmware Update.



Powersoft S.p.A.
Via Enrico Conti, 5
50018 Scandicci (FI) Italy

Tel: +39 055 735 0230
Fax: +39 055 735 6235

General inquiries: info@powersoft.it
Sales: sales@powersoft.it
Application & technical support: support@powersoft.it
Service & maintenance: service@powersoft.it

powersoft-audio.com